

YOUR EVERYDAY COMFORT, EXPLAINED.

Comfort, made simple.

A few easy habits make your Midea mini-split feel effortless.




Midea equipment shown as an example.

THE ONE RULE TO REMEMBER


One system. Same mode.

Operating indoor units sharing one outdoor unit must use the same heating or cooling mode. Choose **HEAT** or **COOL** explicitly.




LIVING ROOM

70°F HEAT



BEDROOM

68°F HEAT



OFFICE

72°F HEAT

Example temperatures shown. Choose what feels comfortable.

Different room temperatures are OK. Opposite modes are not.

Set it. Settle in.

1

Power on

Point the remote toward your indoor unit. Press ON/OFF.

2

Pick a mode

Press MODE to select HEAT (sun) or COOL (snowflake).

3

Find your comfort

Set a temperature you like. Adjust gently as needed.

4

Let it respond

Repeat the mode on connected units. Give the system time.

AUTO mode and AUTO fan are different.

On shared systems, avoid **AUTO operating mode** - it may create a mode conflict. **AUTO fan speed** within HEAT or COOL is OK.




Scan for the
**interactive
guide**

A little care. A lot of comfort.

Know what is normal, what to check, and when to call.

Keep the air moving.



Example: All Easy Pro top-mounted filter. Your model's access may differ.

Check filters about every 2 weeks.

Dust and pets can mean more frequent checks. Follow your model's cleaning instructions.

Clean gently. Dry completely.

Before cleaning, switch off and isolate the power as your manual directs. Wash only washable mesh filters; use mild soap and water, then air-dry in shade. Keep water away from electrical parts.

Give the equipment breathing room.

Keep furniture and curtains clear of indoor airflow. Keep outdoor airflow clear of leaves and snow. Do not chip ice or open service panels.

Before you call.

No heating or cooling?

Check power, remote batteries, MODE and the set temperature. Confirm every unit sharing the outdoor unit is in the same mode.

Just switched modes or restarted?

A protection delay of at least 3 minutes can be normal. Heating warm-up and defrost may take longer. Avoid repeated on/off changes.

Heat paused? Outdoor mist?

In heating, defrost can briefly pause airflow and create steam outdoors. Let the cycle finish. If comfort does not return, call for service.

An error code or standby display?

Take a photo of the exact code. Recheck shared modes, then consult the model's manual or your installer if it persists.

Turn the unit off and get service for indoor leaks, burning smells, loud abnormal noises or repeated breaker trips. Do not keep resetting power.

KEEP YOUR SYSTEM DETAILS HANDY

Model: _____

Installer / service: _____

Use your exact model's manual. Features, codes, filter access and remotes vary. For ceiling units or hard-to-reach filters, ask your installer for safe cleaning help.

Sources & model manuals: scan the guide QR or visit mideacomfort.us/document.html